

The IQAir filter system for IQAir Healthpro 100 or 250 models works as follows:



1. On the Digital Display panel, there is a corresponding light for each filter i.e.,

- F1 = PreMax prefilter
- F2 = V5 Cell Carbon (Healthpro 250 only)
- F3 = HyperHepa ultrafine

**These lights start from green when new; go to orange at 20% remaining; go to red at 5% remaining and red flashing when finished.**



2. Additionally or alternatively, you can dial up the remaining hours left on each filter:

- press MENU to get hours remaining on PreMax
- now press  $\Delta$  to get hours remaining on V5 Cell (Healthpro 250 only)
- now press  $\Delta$  again to get hours remaining on HyperHepa



**RESETTING HOURS FOR NEW FILTERS**

Click through MENU until NEW FILTER appears



Press and hold ENTER until flashing cursor icon appears  
Now press  $\Delta$  to select which new filter needs resetting



• Once relevant filter is selected, press ENTER once for "YES"

• Press ENTER again to confirm and complete.  
Unit should now show updated hours (at speed 1):

1. F1 PreMax 20,000
2. F2 V5 Cell 35,402
3. F3 Hyperhepa 56,206